



CHECKERS

Justrite Safety Group

PARK-IT®

PRODUCT INFORMATION BROCHURE





PICTURED: PARK-IT®

Checkers™ is a full-service manufacturer of parking lot safety solutions. We design and manufacture traffic control products that help cars navigate and park safely. Our main goal has been to create solutions that protect motorists and pedestrians from the perils of today's parking lots. As such, Checkers™ products have been designed and developed with speed reduction, driver and pedestrian safety in mind. All our solutions are manufactured from 100% recycled rubber and plastic. Our speed bumps or parking blocks, for example, are longer lasting, highly visible, and more car-friendly than asphalt or concrete alternatives. Not only are Checkers™ traffic safety solutions environmentally friendly, they can also be installed for either temporary or permanent use.

- **Rubber parking stops greatly outlast concrete competitors**
- **Rubber parking stops don't degrade like concrete parking stops, keeping parking lots aesthetically pleasing**
- **Multiple rubber and tape colors available**
- **High-quality rubber is resistant to weather, salts, and chemicals**
- **Recycled rubber construction is environmentally friendly**
- **Pliable rubber protects vehicles as well as curbs**
- **Highly reflective colored tape ensures the parking stop will be visible**
- **Easy-to-install, either on asphalt or concrete surfaces**
- **Can be used for temporary or permanent applications**
- **Commercial and residential models available**

PRODUCT INFORMATION

Park-It® car stops are used in parking lots to effectively stop cars pulling into parking spots. Unlike asphalt or concrete, which necessitate frequent replacements, Park-It® parking curbs are more forgiving of vehicles, sturdier, and do not break or need to be replaced. Park-It® car stops include in-molded, highly reflective tape in yellow or white, to ensure visibility and pedestrian safety. The rubber stops are pre-drilled with holes. The flexible rubber design conforms to the contour of uneven road surfaces. ADA Handicap Park-It® is designed specifically for handicap parking spaces. The blue and white contrasting colors are immediately identifiable to differentiate handicap parking spaces to vehicles and pedestrians.

Material: Premium recycled rubber

- Long lasting and cost efficient
- Ideal for indoor or outdoor parking
- Will not chip, crack, or fade
- High visibility at night
- Simple installation by one person
- Resistant to ultraviolet light, moisture, oil, and extreme temperatures
- ADA handicap blue available
- 1/10th the weight of standard concrete curb
- Maintenance free
- Warranty: 3 years on the product; 1 year on the tape (under normal use)

⚠ WARNING: This product can expose you to chemicals including Arsenic, Cobalt, Cadmium, Lead, Chromium, Nickel Compounds, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

MODEL: 16101Y



MODEL: 16101W



MODEL: 16101B

APPLICATIONS

- Traffic Control
- Parking Lots
- Facility Protection
- Street Maintenance
- Event Venues
- Residential Areas

SPECIFICATIONS

Model	Description	Length	Width	Height	Weight	Spikes Needed
16101Y	Black w/Yellow Tape	72 in. (182.8 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	34 lbs. (15.4 kg)	4
16101W	Black w/White Tape	72 in. (182.8 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	34 lbs. (15.4 kg)	4
14101Y	Black w/Yellow Tape	48 in. (121.9 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	23 lbs. (10.4 kg)	3
14101W	Black w/White Tape	48 in. (121.9 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	23 lbs. (10.4 kg)	3
13101Y	Black w/Yellow Tape	36 in. (91.4 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	17 lbs. (7.7 kg)	2
13101W	Black w/White Tape	36 in. (91.4 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	17 lbs. (7.7 kg)	2
16201B	ADA Blue w/ White Tape	72 in. (182.8 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	34 lbs. (15.4 kg)	4
14201B	ADA Blue w/ White Tape	48 in. (121.9 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	23 lbs. (10.4 kg)	3
13201B	ADA Blue w/ White Tape	36 in. (91.4 cm)	6 in. (15.24 cm)	4 in. (10.16 cm)	17 lbs. (7.7 kg)	2



CHECKERS™

620 Compton St
Broomfield, CO 80020

PHONE: (800) 438-9336

FAX: (720) 890-4858

EMAIL: sales@checkers-safety.com

www.checkers-safety.com

Ver: 5/19

A PRODUCT OF:



Justrite Safety Group is the leading source of safety equipment for flammables and hazardous materials storage and handling, asset protection, environmental protection spill containment, absorbents, specialized chemical storage, cable management, safety showers, eye/face washes, matting, and vehicle safety equipment. Learn more at Justrite.com, Checkers-safety.com, and Notrax.com.