

Product Specification Sheet

Park-It® Parking Curb **Product Name:**

Manufacturer: NoTrax®, Justrite Safety Group/GNR

> 5655 West 73rd St. Bedford Park, IL 60638

Tel.: (800) 621-2802, Fax: (800) 322-7105

Product Description:

The nominal width and height of the Park-It® parking curb are 6 inches and 4 inches

respectively. Three models available in the below nominal length and weight

36 inches 17 pounds 48 inches 22 pounds 72 inches 34 pounds

The rubber parking curb is outfitted with molded in reflective yellow or white tape for

increased visibility.

Product Specifications:

1. Material: compression molded composite of recycled rubber and polyurethane binder.

2. Physical properties of the rubber composite:

, o		
a) Density	1.04 g/cu. cm	(ASTM C642)
b) Durometer Hardness	65A ± 7	(ASTM D2240)
c) Minimum Tensile Strength*	1.4 MPa	(ASTM D412)
(* main structural areas)		
d) Compression deformation	10% at 0.5 MPa, 68°F	(ASTM D575)
e) Brittleness at Low temperature:	-40°F	(ASTM D746)
f) Freeze and thaw when exposed		(ASTM C672)
to deicing chemicals	no loss after 50 cycles	
g) Coefficient of thermal expansion:	14.4 x10₅ m/m/°C	(ASTM C531)
h) Weathering 70 hours at 158°F		(ASTM D573)

100% (± 5%) - hardness retained - compressive strength 100% (± 5%) - tensile strength 100% (± 5%) - elongation retained 100% (± 5%)

3. Dimensions:

3-Foot Park-It®

width: 6 inches (+/- 0.11 inches) 152mm (+/- 3mm) length: 36 inches (+/- 0.19 inches) 910mm (+/- 5mm) height: 4 inches (+/- 0.11 inches) 102mm (+/- 3mm)



4-Foot Park-It®

 width:
 6 inches (+/- 0.11 inches)
 152mm (+/- 3mm)

 length:
 48 inches (+/- 0.19 inches)
 1219mm (+/- 5mm)

 height:
 4 inches (+/- 0.11 inches)
 102mm (+/- 3mm)

6-Foot Park-It®

 width:
 6 inches (+/- 0.11 inches)
 152mm (+/- 3mm)

 length:
 72 inches (+/- 0.19 inches)
 1929mm (+/- 5mm)

 height:
 4 inches (+/- 0.11 inches)
 102mm (+/- 3mm)

4. Finishing: Black with molded in yellow or white durable reflective tape

5. Product contains: 95% of post- consumer materials and

5% of pre-consumer materials

Installation Method:

Installation on <u>asphalt surfaces</u> with rebar spikes 14" long (minimum diameter ½") (recommended installation).

36 inch (910mm) model – 2 spikes for installation 48 inch (1219mm) model – 3 spikes for installation 72 inch (1829mm) model – 4 spikes for installation

For installation with spikes the 0.5 inch (12.5mm) diameter holes are drilled through the holes in the product into a paved road than the spikes are hammered in.

Installation on concrete surfaces with lag bolts 6" long (minimum diameter 1/2"), washer and shield

36 inch (910mm) model – 2 lag bolts and shields for installation 48 inch (1219mm) model – 3 lag bolts and shields for installation 72 inch (1829mm) model – 4 lag bolts and shields for installation

For installation with lag bolts pilot holes 0.5 inch (12.5mm) are drilled through the product installation holes. The holes are re-drilled for a size required by the shields and the shields are installed. The product is than repositioned over the mounting holes and bolted down.

Warranty:

A three (3) years warranty is provided on the rubber composite and 1 year on the reflective tape if the product is installed as per manufacturer's installation instructions.

The rubber parking curbs are intended to be used for indoor or outdoor parking lots. Any other applications could be considered outside manufacturer warranty.

Please verify with the distributor or the manufacturer if the intended installation location is covered by warranty of the product.

Any warranty claims will be assessed by the product manufacturer after adequate information is provided.

Rev. Jan. 2021