

8ft Lighted Warning Whip with Telescoping Pole and 16" Orange Flag with White Reflective X - TPCWHP8XL-16-O

Product Images



Short Description

- Wide variety of lighting options to choose from
- 8, 10, 13, 15, or 21-foot lengths available
- Tallest whip in the Warning Whips line
- Adjusts quickly with cam-locks
- Coiled wire extends and retracts without binding
- Whip constructed of premium fiberglass resin
- Heavy duty orange Day Bright™® fluorescent nylon mesh flag with 3M® Scotchlite® white reflective X
- Lights sold separately

Description

General-purpose lighted warning whips with telescoping pole are adjustable length whips that extend to 8, 10, 13, 15, and 21 feet. These whips are divided into sections that are connected by cam-locks. To adjust the whip length, simply flip the handle up on the cam-lock to loosen, extend the section(s) to the desired length, and then flip down the handle on the cam-lock to tighten. This easy-to-use system allows you to quickly remove a whip and break it down into a manageable size that can be easily stored in a vehicle. With a high-visibility flag and light, these warning whips provide easy identification of other vehicles, equipment, and important sites in your area. Telescoping pole whips feature a painted white fiberglass pole that protects against fiber bloom and a heavy-duty Day Bright™® fluorescent nylon mesh flag with a 3M® Scotchlite® reflective X. This system requires a hitch mount or flat mount for vehicle attachment. Lighted models feature lamp socket, a superior coiled wire that easily extends and retracts without pinching or binding, and a water-resistant, easy-lock hotplug with 12" pigtail for power connection.

NOTE: Lights are sold separately

Compatible light models: WLFS.4LED.A, WLFS.4LED.AF, WLFS.4LED.B, WLFS.4LED.BF, WLFS.4LED.G, WLFS.4LED.GF, WLFS.4LED.R, WLFS.4LED.RF, WLFS.4LED.W, WLFS.4LED.WF, FSLED12-6-A, FS7020KIT-A, and FS7020KIT-R.

Specifications

Model No	TPCWHP8XL-16-O
UPC	812542025942
Color	white
Quantity Included	1
Whip Length	10
Whip Width	4
Whip Height	4
Whip Collapsed Length (Inches)	62
Flag Size	16 in.
Flag Color	Orange
Flag Reflexite Color	No
Whip Type	Telescoping Rod
Whip Rod Type	Lighted
Flag Shape	Square
Whip Pole Length (ft)	8 ft.

Prop 65

⚠️WARNING: This product can expose you to chemicals including Nickel Compounds, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.