



# Made To Order LED Whip Lights | All-Purpose Lighted Warning Whip™

## Product Images



## Short Description

The Checkers™ All-Purpose LED-Wrapped Waterproof Warning Whips™ with stainless steel components sets the new standard for weather resistance in any working conditions. With multiple patent-pending features, these whips are ideal for extreme weather conditions such as coastal areas, corrosive environments, salt mines, and areas with high humidity.

## Description

- Whip is wrapped with LED lights and covered in clear heat shrink for water-resistant protection  
LEDs come in white, amber, or blue
- Includes a two conductor waterproof hotplug with 12" pigtail, heavy duty Day Bright® fluorescent nylon mesh flag with or without 3M®Scotchlite® reflective X, New Rocket® II Super Bright Waterproof LED light, and a stainless steel threaded hex base
- New patent-pending waterproof LED light socket replaces old 1156 bulb and lamp socket

- Rocket® II Super Bright Waterproof LED comes standard with 9 changeable light modes, 7 flash patterns, and steady on or off, which provides a “one light fits all” solution
- Premium fiberglass resin creates the strongest whip in the industry
- Improved, patent-pending internal ground connection that helps eliminate power failures
- Patent-pending waterproof hot plug connection with two conductor 12" pigtails
- Internal wire is industrial grade and meets Military Spec MIL-W-16878
- Optional stainless steel, powered spring mount available
- Only to be used with 12 volts of power

## Specifications

Model No	BUILD YOUR OWN ALL-PURPOSE LED WRAPPED WHIP
Whip Light Wrap Color	A = Amber B = Blue W = White
Whip Length	3, 5, 6, 8, or 10 ft. Whip
Flag Size	O = Orange G = Green Y = Yellow
Reflexite X Color	W = White Reflective X Y = Yellow Reflective X
LED Light Colors	A = Amber LED AF = Amber Flashing LED B = Blue LED BF = Blue Flashing LED G = Green LED GF = Green Flashing LED R = Red LED RF = Red Flashing LED W = White LED WF = White Flashing LED

## Prop 65

**⚠️WARNING:** This product can expose you to chemicals including Lead, Carbon Black, Chromium, Nickel Compounds, and Sulfur Dioxide, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).