



---

# 12 Pack, 4' x 8' TrakMat® Ground Protection MatPak, 90 Ton Capacity, Black - TMCP4-B

## Product Images

---



## Short Description

---

- Easy, convenient way to transport and store mats
- Mat-Paks include (12) 4' x 8' or 3' x 8' Mats, (20) Single Turn-A-Links, (2) Handi-Hooks, (1) Metal Storage Rack, and (2) Ratchet Strap
- 100% recycled high-density polyethylene (HDPE)
- Supports loads up to 90 tons\*
- Available in black or green
- Contours to different ground conditions due to its flexible design
- Mats can be locked together with Turn-A-Links forming a continuous roadway or workable platform
- Hand holes for easy maneuverability
- Smooth surface available
- Man deployable
- Six-year limited warranty

## Description

---

TrakMAT® Mat-Paks are a convenient, economical package of 12 mats plus accessories and metal storage-skid rack. Mat-Paks include (12) 4' x 8' or 3' x 8' Mats, (20) Single Turn-A-Links, (2) Handi-Hooks, (1) Metal Storage Rack, and (2) Ratchet Straps. Just load the Mat-Pak onto your truck bed and you're set for making a nearly 50 foot roadway to the job site, or you can make a working platform for vehicles and personnel. TrakMAT® has a flexible construction allowing the mats to contour along undulating or sloping ground conditions, preventing rutting or damage to turf. TrakMAT® features a unique power cylinder tread surface on both sides of the mat to improve grip and forward motion of vehicles, with connector points on each corner, we can provide two or four-way tough urethane connectors and stay-put u-stakes to prevent mats from moving creating a firm trackway or work pad. The mat can easily be deployed by a two-person team due to its lightweight design. TrakMAT® ground protection also features 2 hand holes along each long edge to ensure ease of handling. \*Load bearing capacity is subject to ground conditions. Sizing is subject to a manufacturing variance of +/- 5%.

## Specifications

---

Model No	TMCP4-B
UPC	810043332811
Color	Black
Quantity Included	1
Load Capacity	180,000 lbs or 90 Tons
Length (Inches)	96
Width (Inches)	48
Height (Inches)	16

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Carbon Black and Nickel Compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).