

# 12 Pack, 4' x 8' VersaMAT® Ground Protection MatPak, One Smooth Side, 120 Ton Capacity, Black - VMCP4S1

## Product Images



## Short Description

- Easy, convenient way to transport and store mats
- Mat-Paks include (12) 4' x 8' or 3' x 8' Mats, (20) Single Turn-A-Links, (2) Handi-Hooks, (1) Metal Storage Rack, and (2) Ratchet Strap
- 100% recycled high-density polyethylene (HDPE)
- Low-profile VersaMAT® surface on one side and aggressive AlturnaMAT® surface on the other
- Supports loads up to 120 tons\*
- Available in black or clear
- Contours to different ground conditions due to its flexible design
- Mats can be locked together with Turn-A-Links forming a continuous roadway or workable platform
- Limited Lifetime Warranty

## Description

---

VersaMAT® Mat-Paks are a convenient, economical package of 12 mats plus accessories and metal storage-skid rack. Mat-Paks include (12) 4' x 8' or 3' x 8' Mats, (20) Single Turn-A-Links, (2) Handi-Hooks, (1) Metal Storage Rack, and (2) Ratchet Straps. Just load the Mat-Pak onto your truck bed and you're set for making a nearly 50 foot roadway to the job site, or you can make a working platform for vehicles and personnel. VersaMAT® was developed to be a more multi-functional ground protection mat for use where a user is looking for the additional benefit of a walking or standing/working surface with a heavy load capacity for construction equipment. VersaMAT® features a low-profile slip-resistant traction surface making it ideal for pedestrian applications. The standard VersaMAT® has the aggressive AlturnaMAT® tread on one side but is also available with a smooth surface making it truly versatile. Featuring a high load-bearing capacity of 120 tons\*, VersaMAT® can also be used as a vehicle track way, vehicle parking area, or staging area for supplies and equipment. Weighing just 86 lbs (39 kg) at its maximum size, VersaMAT® can be easily be deployed by hand. VersaMAT® is manufactured from 100% recycled high-density polyethylene, making it durable and resistant to all weather conditions. VersaMAT® has a flexible construction meaning that the mat will follow the contours of the ground delivering a highly effective access solution on sloping or undulating ground conditions. VersaMAT® can be connected together using our flat Turn-A-Links or EZ Link connectors ensuring you have a firm and secure trackway.

\*Load bearing capacity is subject to ground conditions. Sizing is subject to a manufacturing variance of +/- 5%.

## Specifications

---

Model No	VMCP4S1
UPC	812542022835
Color	Black
Quantity Included	1
Load Capacity	240,000 lbs or 120 Tons
Length (Inches)	96
Width (Inches)	48
Height (Inches)	16

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Carbon Black and Nickel Compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).