

14" SafeRay™ Hi Viz Aircraft Chock for Narrow Body Aircraft with Locking Rope, Cable Handle and Rubber Pad, Single Chock, Green - AC4614LRRPCHFLG

Product Images



Short Description

- High-visibility fluorescent green urethane material with glow-in-the-dark handle reduces the risk of accidents.
- Up to 50% lighter than rubber aircraft wheel chocks

- Lasts up to 5 times longer than rubber wheel chocks
- Extended ergonomic cable with urethane handle helps mitigate fatigue and injuries
- Resistant to aircraft fuels, oils, and lubricants
- **Sold as a single chock**

Description

Checkers green 14" Hi Viz Aircraft Chock for Narrow Body Aircraft with Locking Rope, Cable Handle and Rubber Pad, model AC4614LRRPCHFLG, is engineered with precision and an unwavering commitment to safety in the aviation industry. Measuring 6-in W x 14-in L x 4.5-in H, it's designed to deliver unparalleled stability and visibility for narrow body aircraft, ensuring the safety of aircraft, operators, and ground personnel alike. Constructed from hi-viz urethane and highlighted with a distinctive green color, this highly visible wheel chock is designed to meet the most stringent safety and performance standards.

Lightweight and Durable Hi Viz Aircraft Chocks

The safety of ramp personnel is non-negotiable. Traditional heavy rubber chocks have been the cause of unnecessary injuries, including head lacerations and shoulder injuries, and their low visibility at night has led to dangerous incidents involving both machinery and personnel. Recognizing these significant pain points, our hi-viz aircraft wheel chocks are lightweight and easy to handle, mitigating fatigue and injuries while ensuring that they are clearly visible in both daytime and nighttime operations.

Featuring a cable loop and urethane handle that last the lifetime of the chock body, our hi-viz urethane wheel chocks typically last longer than rubber wheel chocks. The ergonomic design includes an extended cable with a polyurethane handle, preventing the user from having to bend down to place, remove, or carry the chock, further mitigating fatigue and injuries.

Compliance and Quality Assurance

Adhering to the most stringent standards, our high-visibility aircraft wheel chocks meet FOD (foreign object debris) precautions, Mil-Spec M-32058-1-2-A (AC6820) and M-32058-1-1-A (AC4614) for specific models, SAE AIR4905 guidelines, and FAA and IATA audit standards. Proudly manufactured in the USA, these chocks come with a 1-year warranty against manufacturer defects.

Specifications

Model No	AC4614LRRPCHFLG
Color	Lime Green
Pallet Quantity	240
Length (Inches)	14
Width (Inches)	6
Height (Inches)	4.5
Lanyard Length	36"
Sold As	Single