

Female Ramp for 5-Channel Yellow Jacket® AMS® Modular Accessibility System, ADA Cable Protector for 1" Lines, SafeRay™ Hi-Viz Green - WSA-125-RFAH-FLG

Product Images



Short Description

- Protects cables and hoses up to 1.25" outside diameter
- SafeRay™ Technology in fluorescent green provides the best day and night visibility
- Connect unlimited center sections and add ramps
- Hinged lid for easy cable placement
- Patented technology with modular interlocking design

Description

Use the highly visible fluorescent green 5-Channel Yellow Jacket® AMS® Center® Accessibility Female ADA Ramp (model WSA-125RFAH-FLG) with the Yellow Jacket 5-channel AMS (Advanced Modular System). The Yellow Jacket 5-channel AMS (Advanced Modular System) is a patented technology that utilizes separate cable protector sections and ramps to create a system that is fully expandable to hold an unlimited number of cables. By detaching the ramps, you can also quickly add cable runs and ADA compatible side ramps to existing systems.\

The fluorescent green coloring was created specifically for situations requiring high visibility, using SafeRay™ Technology that provides the best day and night visibility. It features a UV reflective pigment that is added to the urethane blend during production to ensure visibility even in low-light or nighttime applications.

The Yellow Jacket AMS readily handles heavy truck and bus traffic while providing easy access for pedestrians, carts, and wheelchairs. Hinged lids make for easy loading of cables and hoses.

Custom cable protectors can be made with different colors and embossed logos. [Get a quote](#) with your specific requirements.

Specifications

Model No	WSA-125RFAH-FLG
Color	Lime Green
Quantity Included	1
Load Capacity Per Axle	32600 lbs
Length (Inches)	36
Width (Inches)	20.38
Height (Inches)	1.875
Connector Type	Hourglass Connector

Prop 65

⚠️WARNING: ⚠️ This product can expose you to chemicals including Carbon Black, Titanium Dioxide, Formaldehyde, and Benzyl Butyl Phthalate, which are known to the State of California to cause cancer and birth defects or other reproductive harm. ⚠️ For more information go to ⚠️ www.P65Warnings.ca.gov.