

# All-Purpose 8' Warning Whip w/ Orange Flag w/ White Reflective X w/ Pigtail - AP812OW10PT

## Product Images



## Short Description

- Sealed connections prevent corrosion & deterioration
- Premium fiberglass resin backed by a 5-year guarantee not to fiberbloom or expose fiberglass slivers
- Temperature rating of power cable: -75 C/-103 F
- Continuous power cable extends from the lamp through the entire whip and exits through the heavy-duty spring mount

## Description

---

Warning whips are designed to increase the visibility of utility vehicles and small trucks on mine sites. Without a whip for extra visibility, haul truck operators can have difficulty seeing these smaller vehicles, potentially leading to accidents.

The Checkers All-Purpose 8' Warning Whip model AP812OW10PT features a 12" x 12" orange flag with a white reflective X, red LED flashing light and a pigtail base. It is constructed from a premium 8-foot fiberglass resin and threaded ultra heavy duty spring mount for vehicle attachment. It is delivered fully assembled and ready for installation.

To prevent deterioration, a weather-resistant, polyolefin heat-shrink tubing is used to seal the interchangeable lamp socket to prevent moisture, chemicals, and debris from contacting electrical connectors. The hex base is also sealed to provide additional protection.

For improved durability, All-Purpose Lighted Warning Whips With Pigtail feature a high quality, continuous power cable that extends from the lamp through the hex base and heavy duty spring mount. This eliminates pinched wires, multiple solder joints, and hot plug power connections - all of which can cause failure due to corrosion. The custom designed power cable is molded into the whip and consists of 2 conductors, 20 AWG, 19 x 32 strand, triple-coated thermoplastic elastomer (TPE) insulation and features a cold temperature rating of -75 C/-103 F.

All-Purpose Warning Whips have a 5-year guarantee against fiberglass deterioration known as fiber bloom or exposed fiberglass slivers.

# Specifications

Model No	AP812OW10PT
UPC	812542023436
Brand	Checkers Safety™
Color	Orange
Whip Light Color	Red
Whip Light Flashing/Solid	Flashing
Flag Size	11.5
Flag Color	Orange
Flag Reflexite Color	White
Whip Base Type	Spring Mount
Whip Light LEDs	4
Whip Type	Heavy-Duty
Whip Rod Type	Lighted
Flag Shape	Rectangular